




CHASSIS



Reference numbers only are shown in illustration. Use I H part numbers in ordering.

FUEL STRAINER

	355 142 R91	45012	STRAINER, FUEL, w/NUT, 29 899 D " (WILL WORK FOR 38 465 D AND 354 222 R91)		1
1	50 062 D	25904	STEM		501 TO 119975
1	259 403 R91	44801-7	STEM		119976 UP
2	49 928 D	42935-1	BODY, STRAINER		501 TO 90431
2	354 491 R91	44848-2	BODY, STRAINER		90432 TO 119975
2	355 141 R91	45012-2	BODY, STRAINER		119976 UP
3	29 899 D	81-L	NUT, COUPLING		1
4	49 923 D	32278	SCREEN, STRAINER		1
5	49 924 D	32275	GASKET, STRAINER		1
6	49 922 D	32276	BOWL, STRAINER		1
7	50 061 D	32277	NUT AND CUP		1
8	49 947 D	32279	BAIL		1